oraimo
smart accessories

FreePods 3
OEB-E104D

# WELCOME GUIDE

* For safety issue, the product remains low capacity during shipping. Please fully charge the product before initial use!

TRUE WIRELESS STEREO EARBUDS - Model: OEB-E104D
Hereby, ORAIMO TECHNOLOGY LIMITED.
Declares that this Wireless Earphone is in compliance with the essential requirements and other relevant provisions of directive 2014/53/EU.

## PACKAGE CONTENTS

Charging Case x 1 | True Wireless Earbuds x 2 | Type-C Charging Cable x 1

## BASIC PRODUCT SPECIFICATIONS

| EARBUDS | |
|---|---|
| BT version: V5.2 | Music play time: Up to 8 hours |
| Talk range: 10m / 33ft | Battery capacity: 45mAh (Each Earbud) |
| Weight : 4g (Each Earbud) | Charging time: 2 hours |
| Driver (full range): 13mm x 2 | |
| **CHARGING CASE** | |
| Weight: 36g | Battery capacity: 500mAh |
| Charge times for earbuds: Up to 3 times | Charging time: 2 hours |

## PRODUCT OVERVIEW



① Multi-Function Touch Sensor
② Earbud Status Indicator
③ Microphone
④ Type-C Charging Port
⑤ Left Earbud
⑥ Right Earbud
⑦ Case Status Indicator

ONE PAIR, TWO DIFFERENT FITS Awareness Mode / Bass Mode

## FOR INITIAL USE

### Turn On & Pairing

· Remove the protective film

· Charge the product as follow



① Put the earbuds back to the charging case. ② Fully charge the case for 2 hours.

· Turn On

· Pairing

Earbuds will turn on and enter pairing mode automatically for first time use when open the charging case.

| Earbud Status Indicator | | Status |
|---|---|---|
| | Flashing yellow on both earbuds | TWS Pairing |
| | Flashing green and red alternatively on left earbud | BT Pairing |
| | Lights off | Connected to a device |

- Make sure the distance of the earbuds and your device is less than 1 metre / 3.3 feet at the first time of connection.
- When turned on, the earbuds will automatically connect to the last connected device if available. If not, the earbuds will enter pairing mode.
- Under any abnormal condition, return the earbuds to the charging case with the lid closed, then take out again after 15 seconds.
- When left channel and right channel of FreePods 3 are not paired automatically with earbud status indicators flashing red and green alternatively on both earbuds, tap 2 times on both earbuds simultaneously to manually enter TWS pairing mode.

· Turn Off

- The earbuds will automatically turn off after 3 minutes if no device is connected.
- When the earbuds are in the charging case with the lid open and not connected to the phone, it will automatically turn off after 3 minutes.
- When the earbuds are in the charging case and the lid is closed, it will automatically turn off after being fully charged.

## CHARGING YOUR EARBUDS & CASE

### Charging Earbuds

Earbuds will be charged automatically once they are returned to the charging case with the lid closed.

### Charging The Case

| Case Status Indicator | | Status |
|---|---|---|
| | Low battery | Being charged |
| | Middle battery | |
| | High battery | |
| 4s | All lights turn to steady green and then turn off after 4 seconds | Fully charged |

### Case Power Level - After lid closes

| Case Status Indicator | Power Level |
|---|---|
| | Extremely low, charge Immediately |
| | Low |
| | Medium |
| | High |

- Use the included Type-C charging cable to charge the case.
- To preserve battery lifespan, fully charge at least once every 45 days.

## ATTENTION

1. Use original or certified cables;
2. Do not expose to liquids;
3. Do not disassemble;
4. Avoid dropping;
5. Avoid extreme temperatures;
6. Do not use the product outdoors during a thunderstorm;
7. Do not use any corrosive cleaner/oil to clean.

## CONTROLS

| | | |
|---|---|---|
| | ♫ | |
| X 2 | Tap on one earbud twice | Play/Pause |
| L ⊙1.5" | Tap and hold on the left earbud for 1.5 second | Previous track |
| R ⊙1.5" | Tap and hold on the right earbud for 1.5 second | Next track |
| | ☎ | |
| X 2 | Tap on one earbud twice | Answer /End a call |
| ⊙2" | Tap and hold on one earbud for 2 seconds | Reject call |
| | Others | |
| X 3 | During music playback or pause and non-calling status, tap 3 times on one earbud. | Activate Voice Assistant |
| X 3 | When earbuds disconnect, tap 3 times on one earbud. | Clear pairing list and turn off |

## USER TIPS

1. Do not turn up the volume to a high level constantly as this could shorten the service life of this product or impair your hearing;
2. When encounter any fault during operation, please cut off the power supply and disconnect the USB cable to prevent further damage to the product or other components;
3. The wireless transmission range or connectivity could be affected by low battery power. In that case, please recharge immediately.

## CAUTION

1. Risk of explosion if battery is replaced by an incorrect type, dispose of used batteries according to the instructions.
   – disposal of a battery into fire or a hot oven, or mechanically crushing or cutting of a battery, that can result in an explosion;
   – leaving a battery in an extremely high temperature surrounding environment that can result in an explosion or the leakage of flammable liquid or gas;
   – a battery subjected to extremely low air pressure that may result in an explosion or the leakage of flammable liquid or gas.
2. The product shall only be connected to a USB interface of version USB2.0
3. Adapter shall be installed near the equipment and shall be easily accessible.
4. EUT Temperature: :-20℃～+60℃(Standalone); 0~+40℃(with adapter).

Operating Frequency: BT: 2402-2480MHz
Modulation mode: GFSK, π/4-DQPSK, 8DPSK GFSK(BLE)
RF output power: BT: 0-10dBm

Figure 1 - Warning label (EC 60417-6044)

Scan to Visit Our Website
contact@oraimo.com
us.oraimo.com

Keep Exploring